

This machine requires an adult to operate. No one, under the age of 18, may operate this machine. The operator must read and follow all safety precautions and instructions.

To Operate Sno-Kone Machine

1. Load hopper with ice. Fill with ice cubes within 1" from the top.
2. Close pusher handle.
3. Turn power switch to the "On" position.
4. Apply downward pressure on pusher handle while holding red momentary shave ice switch. The momentary switch is a safety precaution. A firm, even pressure is best. Relieve the pressure two or three times with each batch of ice to let the ice rearrange itself. Do not force the handle too much or the motor could stall. Too much pressure on the ice will make the shaved ice coarse; too little pressure makes the ice mushy.
5. Do not lift the pusher handle until the motor is off and the shaver head is stopped.
6. After desired amount of shaved ice is made, simply scoop shaved ice into cups, and top with syrup. A little syrup goes a long way.
7. Do NOT remove ice from hopper. Once it is in the hopper, it must be shaved, no exceptions.

Never allow any foreign or metallic objects around the shaver area of the Sno-Kone Machine. Ice picks, scoops, and debris that may be in the ice often damage blades.

To Clean:

Run motor until there is no longer any ice in hopper or being shaved. Continue to run motor for an additional 30-45 seconds to remove excess water from blades.

Turn off motor, unplug the unit.

Empty any unused shaved ice from holding area and dry up excess water with paper towels or cloth.